
Vista 40 Programming

Vista 40 Programming

*Downloaded from
old.oplm.com by
Mohammed & Lexi*

INTRODUCTION

For security professionals and dedicated DIY homeowners alike, few names carry as much weight in the residential and light commercial alarm industry as Honeywell. Among its extensive lineup of control panels, the **Vista 40** stands out as a reliable, feature-rich platform that has protected countless properties for years. However, the true power of this security system lies not in its hardware

but in its flexibility. Mastering **Vista 40 programming** unlocks the ability to tailor every sensor, zone, and response to the unique needs of a building. Whether you are configuring entry delays, setting up wireless zones, or integrating with a central monitoring station, understanding how to navigate the programming menu is essential.

This guide provides a comprehensive, step-by-step look at Vista 40 programming. Written for both experienced installers and motivated homeowners, it covers everything from

entering installer code to troubleshooting common errors. By the end, you will have a clear roadmap to either program a brand-new panel or modify an existing installation without frustration.

UNDERSTANDING THE HONEYWELL VISTA 40 OVERVIEW

The Honeywell Vista 40 is a versatile security control panel that supports up to 48 zones (8 hardwired and 40 wireless via a 5881 receiver). It is part of the broader Vista family, known for its robust performance and compatibility with a wide range of sensors, keypads, and communicators. Before diving into programming specifics, it is important to understand the panel's core architecture and user interface.

Key Components of the Vista 40 System

- **Main Control Board:** Houses the microprocessor, onboard zone inputs, power connections, and communication terminals.
- **Keypad:** The primary interface for programming and daily operation. Common models include the 6160, 6150, and 6160RF.
- **Wireless Receiver (optional):** Models like the 5881ENL enable the system to use wireless sensors.

- **Communicator:** Allows the panel to dial a central station or send alerts via cellular or IP modules.

Programming the Vista 40 is accomplished almost exclusively through the keypad using a series of menu-driven commands. The system uses a **data field** approach: each programmable setting is stored in a numbered field (e.g., *41, *42). This structure makes it systematic once you learn the field numbers.

GETTING STARTED WITH VISTA 40 PROGRAMMING

Before you can change any settings, you must enter the proper programming mode. The Vista 40 has multiple levels, but the most common for full system

configuration is the **Installer Programming Mode**. This requires the factory default installer code, which is typically **4112** (unless previously changed).

Entering Installer Programming Mode

1. Press and hold the **[#]** key for about two seconds until the keypad beeps and the display changes.
2. Key in the installer code (default: 4112).
3. The keypad will show “Installer

Code XX” – press **[8]** to enter the programming menu.

4. You are now in installer programming. The keypad will display “Field Code? – ” or a similar prompt.

Important: While in installer programming, all alarm reporting is suspended, and zones may be unresponsive. Exit programming mode by pressing **[98]** (or **[99]** on some firmware versions) to save changes and reboot the panel.

Navigating the

Data Fields

Once inside installer programming, you enter a field number (e.g., *41 for zone 1 type) and press **[*]** to view or change its value. Use the keypad digits to input numbers, and press **[*]** again to advance to the next field. Press **[#]** to go back to the previous field. This simple navigation makes Vista 40 programming efficient once you memorize the relevant field codes.

ESSENTIAL VISTA 40 PROGRAMMING FIELDS

The Vista 40 has hundreds of data fields, but the most frequently used ones fall into a few categories: zone definitions, system timers, partition options, and

communication settings. Below are the critical fields you will encounter in almost every installation.

Zone Programming (Fields *41 through *48 and *50 through *58)

Each zone must be assigned a **zone type** (e.g., Perimeter, Interior, Fire, 24-Hour) and an **input type** (normally closed, EOL resistor, etc.). For hardwired zones (1-8), use fields *41 through *48.

For wireless zones (9-48), you assign zone types in fields starting at *50.

- **Zone Type Values (examples):**
 - 00 – Entry/Exit #1 (delay)
 - 01 – Entry/Exit #2 (delay, longer)
 - 03 – Perimeter (instant)
 - 04 – Interior (follow)
 - 05 – Day/Night
 - 09 – Fire (24-hour)
 - 16 – 24-Hour Audible (panic)
- **Zone Input Type (for hardwired zones in field *40):**
 - 01 – Normally Closed (NC)
 - 02 – Normally Open (NO)
 - 03 – Single EOL (End of Line) resistor
 - 04 – Double EOL resistor

Example: To program zone 2 as a

perimeter door (instant), type *42, then press [*], enter 03, press [*] to save. If it is a hardwired zone, ensure the wiring matches the input type set in field *40.

System Timers (Fields *34 and *36)

These control how long the system waits for you to enter an exit door (exit delay) and how long it gives you to disarm after re-entering (entry delay).

- ***34 (Exit Delay):** Enter value in seconds (maximum 255). Common settings: 60 or 90.
- ***36 (Entry Delay):** Also in

seconds. Typically 30 or 45.

Note: Entry delay 1 applies to zones programmed as Entry/Exit #1; Entry/Exit #2 uses a separate timer (field *37).

Communication and Reporting (Fields *29, *30, *40, *41, etc.)

To send alarm signals to a central station, you must program the phone numbers (or IP/cellular paths) and account information.

- ***41 (Primary Phone Number):**

Up to 20 digits. Use [*] for a pause, [#] for a second dial tone detection.

- ***42 (Secondary Phone Number):** Backup number.
- ***29 and *30 (Account Numbers for Primary/Secondary Reporting):** Usually 4 or 6 digits.

For modern communicators (e.g., IP module), you may need to enter the module's programming mode separately, but the account numbers on the panel still apply.

Partitioning

(Field *00, *01, etc.)

The Vista 40 supports up to 8 partitions. Field *00 allows you to assign zones to specific partitions. Partitioning is advanced and often used in commercial settings where multiple users need independent areas. For most residential installations, keep everything in Partition 1.

STEPS TO PROGRAM WIRELESS ZONES ON VISTA 40

Wireless programming is one of the most common tasks because many installs use battery-powered sensors. Before programming, the wireless receiver must

be properly installed and recognized by the panel. Then follow these steps:

1. Enter Installer Programming Mode.
2. Go to field ***50** to start programming wireless zone types. The format is zone type (two digits) followed by the serial number (10 digits for Honeywell 5800 series).
3. For example, to program wireless zone 9 as a perimeter (type 03) with serial number 1234567890: type ***50**, press **[*]**, enter **031234567890**, then press **[*]**.
4. Repeat for additional zones (fields ***51**, ***52**, etc., up to zone 48).
5. Some wireless devices (like 5800PIR) also require you to learn the serial number from the

device's tamper mode. Press and hold the tamper switch while entering the serial manually, or use the "zone programming" keypad shortcut in some firmware.

Tip: Keep a written record of which serial number corresponds to which zone for future troubleshooting.

COMMON CHALLENGES AND TROUBLESHOOTING IN VISTA 40 PROGRAMMING

Even experienced installers occasionally hit roadblocks. Here are typical issues and how to resolve them.

“Communication Busy” or Keypad Not Responding Zones Not Reporting Correctly

If the keypad shows “COMM BUSY” or “SYSTEM BUSY” when trying to enter installer mode, the panel might already be in programming remotely, or there is a short on the data bus. Check keypad wiring (red/black/green/yellow) and ensure no other installer is connected via an IP module. Reboot the panel by removing AC and battery for 30 seconds, then reapply.

- **Check the zone type:** For example, a door programmed as “interior” will never cause an instant alarm when open during disarmed state—it will only trip when armed away.
- **Verify wiring:** Hardwired zones must have a proper end-of-line resistor (if using EOL) and no shorts. For wireless, confirm the serial number is correct and the device is enrolled (the panel

acknowledges the serial).

- **Zone input type:** If you're using double EOL resistors, ensure field *40 is set to 04. Otherwise, the panel will not read the resistor correctly.

Panel Beeping After Programming

After exiting installer mode, a beeping panel often indicates a trouble condition. Press **[1]** then **[*]** while keypad shows "Ready" to view trouble list. Common troubles include low battery on a wireless sensor, AC loss, or a zone that is

still open. Clear the trouble to stop the beeping.

Cannot Exit Installer Mode

If pressing **[98]** or **[99]** doesn't exit, you may be in a sub-menu. Press **[#]** repeatedly until you see "Field Code? - " then try exit again. On rare occasions, a corrupted field will hang the system - cycle power to force an exit.

BEST PRACTICES FOR EFFICIENT VISTA 40 PROGRAMMING

To avoid mistakes and save time, follow these professional tips:

- **Use a checklist:** Write down all

intended zone types, timers, and phone numbers before starting.

- **Default the panel first:** If inheriting a used system, factory reset by entering installer mode and setting field ***90** to the default value (usually **02** for a full default of all fields). Wait for panel to reboot.
- **Test each zone immediately:** After programming a zone, exit installer mode and physically trip the sensor to confirm the correct response.
- **Label everything:** Use the keypad's zone text feature (field *80-*87) to assign custom names

like "Front Door" or "Garage Window." This makes operation easier for end-users.

- **Keep firmware notes:** Older Vista 40s may have slightly different field behavior (e.g., wireless zone serial format). Check the version by entering installer mode and pressing **[1]** to view firmware date.

ADVANCED PROGRAMMING: OUTPUTS AND AUTOMATION

The Vista 40 also includes programmable outputs (e.g., triggers for sire