

Badger Range Guard Installation Manual

Badger Range Guard Installation Manual

Downloaded from [old.oplm.com](#) by Foley & Carter

INTRODUCTION TO THE BADGER RANGE GUARD INSTALLATION MANUAL

Installing a kitchen safety device like the **Badger Range Guard** can significantly reduce the risk of gas-related accidents in your home. Whether you are a professional installer or a confident DIY homeowner, having a clear understanding of the **Badger Range Guard Installation Manual** is essential for a safe, efficient, and code-compliant setup. This comprehensive guide walks you through every step of the process, from unpacking the unit to final testing. We will cover the tools you need, safety precautions, mounting options, wiring requirements, and troubleshooting tips—all presented in a straightforward, human-readable style that respects SEO best practices.

The Badger Range Guard is designed to automatically shut off the gas supply to your stove or cooktop when it detects an unattended burner, a flame-out, or excessive heat. Proper installation ensures that the guard functions reliably for years, protecting your family and property. This article serves as an extension of the official manual, offering clarity on common pitfalls and supplementary advice for a seamless installation experience.

WHAT IS THE BADGER RANGE GUARD?

Before diving into the installation steps, it helps to understand what the Badger Range Guard is and how it works. The device is a smart safety system that mounts above your gas range. It uses infrared sensors to monitor burner activity. If the sensors detect that a burner has been left on for too long without significant pot movement, or if the flame is extinguished unexpectedly, the guard automatically triggers a solenoid valve to cut off the gas supply. It also includes an audible alarm to alert occupants.

The **Badger Range Guard** is widely used in residential kitchens, rental properties, and commercial settings to comply with fire safety regulations. Its installation manual provides detailed instructions for wall mounting, wiring, and sensor calibration. Following that manual to the letter is important, but sometimes additional context helps—especially for first-time installers.

PRE-INSTALLATION CHECKLIST: WHAT YOU NEED

Tools and Materials

Before you begin, gather the following items as recommended in the **Badger Range Guard Installation Manual**:

- Electric drill with appropriate drill bits (masonry bit for tile, wood bit for studs)
- Phillips and flathead screwdrivers
- Wire strippers and crimping tool
- Voltage tester (non-contact)
- Measuring tape and pencil
- Level
- Safety glasses and gloves
- Mounting screws and wall anchors (typically included)
- Cable clamps or cable ties
- Optional: stud finder for drywall installations

Safety Precautions

Always turn off the main gas supply and the electrical power to the range before starting. The manual emphasizes that the Badger Range Guard must be connected to a dedicated 120V AC outlet or hardwired by a licensed electrician. Do not attempt to modify the internal wiring. If you smell gas at any point, stop work immediately and call a professional.

STEP-BY-STEP INSTALLATION PROCESS

Step 1: Choose the Mounting Location

The **Badger Range Guard Installation Manual** specifies that the unit should be mounted on the wall behind the range, centered above the cooktop, and at a height of 24 to 30 inches from the burner grates to the bottom of the guard. This distance ensures optimal sensor coverage. Use a level to mark the position of the mounting bracket.

If you have a backsplash made of tile, stone, or glass, you may need a carbide-tipped drill bit. For drywall, locate a stud or use heavy-duty toggle bolts to support the weight of the unit (the guard itself is lightweight, but the solenoid valve adds some mass).

Step 2: Install the Mounting Bracket

Drill pilot holes at the marks and insert wall anchors if needed. Secure the bracket with screws provided in the kit. Double-check that the bracket is level—any tilt can affect sensor alignment. The manual recommends leaving a small gap between the bracket and the wall to allow for cable routing.

Step 3: Mount the Guard Unit

Align the slots on the back of the Badger Range Guard with the tabs on the bracket. Push the unit downward until it clicks into place. Gently tug to confirm it is locked. Some models also have a secondary screw that secures the unit to the bracket—consult your manual for specifics.

Step 4: Connect the Gas Line

This is the most critical part of the installation. The Badger Range Guard includes a gas solenoid valve that must be installed inline with the gas supply to the range. The manual provides a gas connection diagram. Typically, you will need to:

1. Shut off the gas at the main valve.
2. Disconnect the existing gas line from the range.
3. Attach the solenoid valve to the gas line using appropriate fittings (usually 1/2-inch NPT).
4. Reconnect the gas line to the range outlet.
5. Apply pipe joint compound or Teflon tape on all threaded connections.

Important: If you are not comfortable working with gas lines, hire a licensed plumber or gas fitter. Leaks can be deadly. Once the connections are made, use a gas leak detector solution or soapy water to check for bubbles at every joint. Tighten if necessary until no leaks appear.

Step 5: Electrical Wiring

The Badger Range Guard requires a 120V AC power source. The unit comes with a pigtail cord (typically 3 feet long) or a terminal block for hardwiring. The manual instructs you to connect the black (hot) wire to the black supply, white (neutral) to white, and ground (green or bare) to the ground wire or metal junction box. Use wire nuts and ensure no exposed copper protrudes.

For plug-in models, simply plug the cord into a nearby grounded outlet. Avoid using extension cords. If you are hardwiring, consider installing a dedicated circuit to prevent overloading. A licensed electrician should perform this step if you are not experienced with home wiring.

Step 6: Sensor Alignment and Calibration

Once the unit is mounted and connected, power it on. The **Badger Range Guard Installation Manual** describes an automatic self-test sequence. The LED indicators will flash, and the alarm may sound briefly. After the self-test, you may need to align the infrared sensors. Many models have adjustable sensor brackets that let you tilt the sensor head slightly to cover the entire burner area.

To calibrate, light a burner on the range and observe the guard's response. The unit should detect the flame within a few seconds and show a steady green or blue light. If the sensor does not detect the burner, use a small Allen wrench to adjust the sensor angle as described in the manual. Repeat for each burner.

Step 7: Test the System

Testing is crucial. The manual provides a test sequence that you should perform at least once after installation:

- Turn on a burner and let it run for 30 seconds.
- Simulate an unattended condition by leaving the burner on and stepping away. After a preset time (usually 30–60 seconds in test mode), the alarm should sound and the gas valve should close, extinguishing the flame.
- Reset the unit by turning the burner off and pressing the reset button on the guard (if equipped).
- Test the flame-out detection by blowing out a burner flame—the guard should shut off within seconds.

If any test fails, review the manual's troubleshooting section. Common issues include poor sensor alignment, loose wiring, or low voltage. Contact customer support if problems persist.

MAINTENANCE AND ONGOING USE

After installation, the Badger Range Guard requires little maintenance. Clean the sensor lens periodically with a soft, dry cloth to remove grease or dust buildup. Do not use abrasive cleaners. The manual suggests testing the system once a month to ensure proper operation.

Battery backup: Some models have a battery compartment for power failure situations. Replace batteries every year or as indicated by the low-battery alarm.

TROUBLESHOOTING COMMON ISSUES

Even with careful installation, you may encounter problems. Here are solutions from the **Badger Range Guard Installation Manual**:

- **Unit does not power on:** Check the circuit breaker, outlet, or wiring connections. Ensure the unit is properly seated on the bracket and that the power cord is fully inserted.
- **Sensors not detecting flame:** Adjust sensor angle. Ensure the burner is clean and the flame is blue (yellow flames can interfere). Also, check that no large pots or pans block the sensor view.
- **Gas valve does not close:** Listen for a click when the solenoid activates. If no click, the valve may be faulty or the wiring to the valve may be loose. Turn off gas and inspect connections.
- **False alarms:** Steam from boiling water or high ambient heat can occasionally trigger the guard. Reduce sensor sensitivity if adjustable, or relocate the unit slightly higher.

COMPLIANCE AND CODE CONSIDERATIONS

Many regions require gas range safety devices in rental properties or new construction. The Badger Range Guard meets UL and CSA standards. The manual includes a section on local codes, emphasizing that installation must follow the National Fuel Gas Code (NFPA 54) and local electrical codes. Keep a copy of the manual and installation records for inspection purposes.

CONCLUSION

Installing the Badger Range Guard is a smart investment in kitchen safety. By following the **Badger Range Guard Installation Manual** step by step—from gathering tools to final testing—you can ensure that the device operates correctly and protects your household from gas-related hazards. Remember to prioritize safety when working with gas and electricity, and do not hesitate to call a professional if any step feels beyond your skill level. A well-installed range guard gives you peace of mind every time you cook.