
Principles Fire Behavior And Combustion

*Principles
Fire Behavior
And
Combustion*

*Downloaded
from
old.oplm.com
by Cowan &
Howard*

UNDERSTANDING THE CORE PRINCIPLES OF FIRE BEHAVIOR AND COMBUSTION

Fire is one of the most powerful and fundamental forces on Earth. It can provide warmth, enable industry, and cook our food, yet it can also cause catastrophic destruction in a matter of minutes. To understand how to control, prevent, or

suppress fire effectively, one must first grasp the scientific **principles of fire behavior and combustion**. This knowledge is essential not only for firefighters and safety professionals but also for engineers, architects, and anyone responsible for managing fire risks in the built environment. At its most basic level, fire is a rapid chemical reaction known as combustion. This reaction occurs when a fuel source combines with an oxidizing

agent, typically oxygen, in the presence of sufficient heat. However, the reality of how fires start, grow, spread, and decay involves a complex interplay of chemistry, physics, and thermodynamics. By dissecting the essential principles, we can better predict fire behavior, design safer buildings, and implement effective suppression strategies.

THE FIRE TETRAHEDRON: THE FOUR PILLARS OF COMBUSTION

Historically, fire was explained using the "fire triangle," which consisted of three elements: heat, fuel, and oxygen. While this model is useful for basic understanding, modern fire science has expanded it into

the **fire tetrahedron**. This four-sided model adds the fourth and critical element: the chemical chain reaction. For a fire to exist and sustain itself, all four elements must be present in the correct proportions.

Heat: The Ignition Source

Heat is the energy required to raise the temperature of a fuel to its ignition point. This energy can come from many sources, including open flames, sparks, friction, electrical arcs, or even the sun. Without a sufficient heat source, the fuel cannot vaporize or decompose into the gases

necessary for combustion. Understanding how heat is generated and transferred is foundational to the **principles of fire behavior and combustion.**

Fuel: The Material That Burns

Fuel is any material that can undergo combustion. Fuels can be solid (wood, paper, textiles), liquid (gasoline, alcohol, oil), or gas (propane, methane, hydrogen). The physical and chemical properties of the fuel significantly influence how a fire behaves. Key

characteristics include the fuel's calorific value, its surface area-to-mass ratio, its moisture content, and its volatility. For instance, finely divided fuels like sawdust ignite far more easily than a solid log because they have a much larger surface area exposed to heat and oxygen.

Oxygen: The Oxidizer

Oxygen is the most common oxidizing agent in fires, though other chemicals can serve this role under specific circumstances. Ambient air contains approximately 21 percent oxygen by volume. Most fires

require at least 16 percent oxygen to sustain combustion. When the oxygen concentration is reduced below this threshold, the fire will typically dim or extinguish. This principle is the basis for many suppression techniques, such as smothering a fire with foam, carbon dioxide, or a fire blanket.

The Chemical Chain Reaction: Sustaining the

Flame

The fourth side of the tetrahedron represents the self-sustaining chemical chain reaction. Once ignition occurs, the heat released from the combustion reaction breaks down additional fuel molecules into free radicals. These highly reactive particles then combine with oxygen to release even more heat, perpetuating the cycle. If this chain reaction is interrupted by a suppression agent like dry chemical powder or halon, the fire will extinguish even if heat, fuel, and oxygen remain present. This is a sophisticated aspect of the **principles of fire behavior and combustion** that distinguishes a

sustained fire from a simple ignition event.

THE PHASES OF FIRE DEVELOPMENT

Fires rarely remain static. They typically progress through a series of distinct stages, each with its own characteristics and hazards. Recognizing these stages is crucial for anyone involved in firefighting, fire investigation, or fire prevention.

Incipient Stage

The incipient, or ignition, stage is the very beginning of a fire. At this point, the fire is small, localized, and typically confined to the immediate area

around the ignition source. The fire plume rises upward, and the oxygen concentration in the room is still near normal levels. A small flame from a match or a smoldering cigarette represents the incipient stage. Fires detected and addressed during this phase are often the easiest to control, making early warning smoke detectors invaluable.

Growth Stage

As the fire continues to burn, it enters the growth stage. The fire begins to spread to nearby fuel packages, such as furniture, curtains, or building materials. The heat release rate increases, and a hot gas layer

begins to accumulate near the ceiling. This layer consists of smoke, unburned gases, and superheated air. During this stage, the fire is highly dependent on the availability of oxygen and the configuration of the compartment. If the fire is in a closed room with limited ventilation, it may become ventilation-limited, meaning its growth is constrained by the available oxygen.

involved in the fire. The heat release rate is at its maximum, and temperatures can soar to over 1,000 degrees Celsius. This is the most dangerous phase for occupants and firefighters alike. Structural elements may begin to fail, and the risk of collapse increases dramatically. Flashover, a phenomenon we will discuss shortly, marks the transition from the growth stage to the fully developed stage.

Fully Developed Stage Decay Stage

The fully developed stage represents the peak of fire intensity. At this point, the entire compartment is

Eventually, the fire will enter the decay stage as the available fuel is consumed or the oxygen supply is depleted. The heat release rate decreases, and temperatures

begin to drop. The fire may transition into smoldering combustion or self-extinguish entirely. However, the decay stage is not without risk. Smoldering fires can produce large quantities of carbon monoxide and other toxic gases. If a source of fresh oxygen is suddenly introduced, such as by opening a door, the fire can rapidly reignite or even cause a backdraft explosion.

KEY FIRE BEHAVIOR PHENOMENA

A deep understanding of the **principles of fire behavior and combustion** requires familiarity with several critical phenomena that can dramatically alter the course of a fire. These events are

often sudden, violent, and extremely hazardous.

Flashover

Flashover is the near-simultaneous ignition of all combustibile surfaces within a compartment. It occurs when the hot gas layer at the ceiling radiates enough heat back down to the floor, causing all exposed fuels to reach their ignition temperature at roughly the same time. The transition to flashover is a defining moment in fire development. Once flashover occurs, survival inside the compartment is virtually impossible without specialized protective equipment. Understanding the conditions that lead to flashover is a

cornerstone of modern fire safety engineering.

Backdraft

Backdraft is a dangerous explosion that can occur when a fire in a ventilation-limited environment suddenly receives a supply of fresh oxygen. The fire has been consuming oxygen and producing flammable gases like carbon monoxide. When a door or window is opened, the rush of oxygen mixes with these unburned gases. If the gases are within their flammable range and a source of ignition exists, the result is a violent explosion that can send a fireball outward with tremendous force. This is why firefighters are trained to ventilate buildings carefully and

to use thermal imaging cameras to detect potential backdraft conditions.

Rollover

Rollover, also known as flame extension, occurs when unburned fire gases at the ceiling ignite and form a rolling ball of flame across the ceiling surface. While rollover is not as immediately destructive as flashover, it is a strong indicator that flashover is imminent. Firefighters observing rollover in a structure understand that they have very little time to take action before conditions become untenable.

MODES OF COMBUSTION

Not all fires burn in the same way. The mode

of combustion depends on the type of fuel, the availability of oxygen, and the temperature of the environment. The two primary modes are flaming combustion and smoldering combustion.

Flaming Combustion

Flaming combustion is the most recognizable form of fire. It occurs when gases and vapors released from a fuel mix with oxygen and ignite. The flame is the visible manifestation of the gas-phase reaction. Flaming combustion is generally efficient, producing large amounts of heat and light, along with carbon dioxide and water

vapor when sufficient oxygen is present. This is the typical mode of combustion for most building fires involving materials like wood, paper, plastics, and flammable liquids.

Smoldering Combustion

Smoldering combustion is a slow, low-temperature, flameless form of combustion. It occurs on the surface of a solid fuel, such as a cigarette, a pile of sawdust, or upholstery foam. Smoldering is sustained by the heat generated from oxidation at the fuel surface. It is an inefficient form of

combustion that produces high yields of carbon monoxide and other toxic compounds. Smoldering fires can persist for hours or even days before transitioning to flaming combustion, making them a major cause of fire fatalities in residential settings.

HEAT TRANSFER MECHANISMS IN FIRE

Fire spreads through the transfer of heat from the burning fuel to unburned fuel. There are three primary mechanisms of heat transfer: conduction, convection, and radiation. Each plays a critical role in fire growth and spread.

Conducti on

Conduction is the transfer of heat through a solid material. When one end of a metal beam or pipe is heated, the heat travels through the material by molecular vibration. In a fire, conduction can cause ignition at a distance from the original fire source. For example, a steel beam heated by a fire on the floor below can ignite combustible materials on the floor above. The thermal conductivity of a material determines how quickly and efficiently it transfers heat. Metals like copper and steel are excellent conductors, while materials like wood and gypsum are

poor conductors.

Convection

Convection is the transfer of heat through the movement of fluids, including gases. In a fire, hot gases rise because they are less dense than the surrounding cooler air. This creates a convection current that carries heat upward toward the ceiling. The hot gas layer that forms at the ceiling is a direct result of convection. This layer can then radiate heat downward, contributing to the spread of the fire. Convection is the dominant mode of heat transfer in the early stages of a compartment fire.

Radiation

Radiation is the transfer of heat through electromagnetic waves. Unlike conduction and convection, radiation does not require a medium; it can travel through a vacuum. In a fire, radiation is responsible for heating objects that are not in direct contact with the flames. For example, a burning building can ignite the roof of a neighboring building purely through radiant heat transfer. The intensity of radiation increases dramatically with temperature, which is why the radiant heat from a flashover event is so lethal.

CLASSIFICATION AND ITS ROLE IN COMBUSTION

Understanding the type of fuel involved in a fire is essential for selecting the correct suppression agent. Fires are commonly classified into five categories based on the fuel source.

- **Class A Fires:**

These involve ordinary combustible materials like wood, paper, cloth, rubber, and some plastics. Water is the most common and effective suppression agent for Class A fires because it cools the fuel below its ignition temperature.

- **Class B Fires:**

These involve flammable liquids and gases, such as gasoline, oil, propane, and solvents. Water is generally ineffective and can even spread the fire. Foam, dry chemical, and carbon dioxide are typical agents used to suppress Class B fires.

- **Class C Fires:**

These involve energized electrical equipment. Using water or conductive agents poses a severe risk of electrocution. Non-conductive agents like dry chemical powder or carbon dioxide

are required.

- **Class D Fires:**

These involve combustible metals such as magnesium, titanium, sodium, and potassium. These fires require specialized dry powder agents that smother the fire and absorb heat. Water is extremely dangerous on Class D fires.

- **Class K Fires:**

These involve cooking oils and fats typically found in commercial kitchens. Wet chemical agents designed to saponify the oil are the preferred suppressant.

This classification system is a practical application of the **principles of fire behavior and combustion**. By understanding the chemical and physical properties of each fuel type, fire protection engineers can design systems that deliver the right agent in the right quantity at the right time.

PRACTICAL APPLICATIONS OF COMBUSTION PRINCIPLES

The scientific understanding of fire behavior is not merely academic. It has direct, practical applications in fire prevention, firefighting, and building design