

---

# Geometric Dimensioning And Tolerancing Examples

---

*Geometric Dimensioning And  
Tolerancing Examples*

*Downloaded from [old.oplm.com](http://old.oplm.com) by  
Goodman & Patricia*

---

## INTRODUCTION TO GEOMETRIC DIMENSIONING AND TOLERANCING (GD&T)

---

In the world of precision engineering and manufacturing, the difference between a perfectly functioning assembly and a costly scrap pile often comes down to how well the design communicates its requirements. This is exactly where **Geometric Dimensioning and Tolerancing (GD&T)** shines. Instead of relying solely on traditional plus/minus tolerances that can lead to ambiguity, GD&T uses a symbolic language to define the allowable variation in part geometry. It ensures that every engineer, machinist, and quality inspector understands the exact functional intent of a feature. To truly appreciate its power, nothing beats exploring real-world **Geometric Dimensioning and Tolerancing Examples**. This article walks you through practical applications, from simple hole locations to complex profile controls, all while explaining the underlying principles in a clear, human-friendly manner.

---

## WHY GD&T MATTERS: MOVING BEYOND COORDINATE

---

---

## TOLERANCING

---

Before diving into examples, let's briefly revisit why GD&T became essential. Traditional coordinate tolerancing (like  $\pm 0.1$  mm on a hole center) creates a square tolerance zone. This zone allows larger variation at the corners than at the center, which may unnecessarily reject perfectly functional parts or accept out-of-spec parts. GD&T, on the other hand, uses cylindrical or shaped tolerance zones that more accurately reflect assembly requirements. For instance, a **positional tolerance** for a hole defines a circular zone, guaranteeing a consistent fit regardless of direction. This difference becomes apparent when we look at specific geometric dimensioning and tolerancing examples.

---

## EXAMPLE 1: TRUE POSITION OF A HOLE PATTERN

---

Imagine you are designing a mounting plate with four bolt holes that align with a corresponding part. Using conventional tolerances, you might call out the hole centers as 100 mm  $\pm 0.2$  mm and 50 mm  $\pm 0.2$  mm. But what happens if one hole shifts diagonally? The assembly might still work, yet the part could be rejected because each coordinate is out of tolerance. With GD&T, you specify a **true position** tolerance, such as:

- **Feature:** Four 10 mm diameter holes

- **Tolerance:** Positional tolerance of 0.4 mm at MMC (Maximum Material Condition)
- **Datum references:** A (primary), B (secondary), C (tertiary)

Here, the tolerance zone is a cylinder of 0.4 mm diameter centered at the theoretically exact location. The allowed variation is equal in all directions. Furthermore, the MMC modifier allows a bonus tolerance if the hole is larger than its minimum size (e.g., if the hole diameter is 10.1 mm, the positional tolerance increases to 0.5 mm). This is a classic example from geometric dimensioning and tolerancing examples where GD&T saves money by accepting more parts without compromising function.

## Practical Interpretation

When a machinist sees this callout, they know exactly what to inspect: the actual hole center must lie within a 0.4 mm diameter cylinder at the true position. The bonus tolerance at MMC means they can use functional gages—a simple pin gage that checks both hole size and location simultaneously. This avoids complex coordinate measurements and ensures the part will assemble correctly every time.

### **EXAMPLE 2: PERPENDICULARITY OF A PIN TO A BASE**

Consider a precision guide pin that must stand perfectly perpendicular to a mounting surface. If the pin leans even slightly, the moving carriage will bind or wear unevenly. A simple perpendicularity callout using GD&T looks like this:

**Callout:** A perpendicularity symbol ( $\perp$ ) with a tolerance of 0.05 mm relative to datum plane A.

This means the axis of the pin must be contained within a cylindrical tolerance zone of 0.05 mm diameter that is perpendicular to datum A. In simpler terms, the pin can tilt only as much as allowed by that 0.05 mm cylinder. Unlike an angle tolerance, this directly controls the deviation from 90° in a way that accounts for both direction and magnitude. This is one of the geometric dimensioning and tolerancing examples that eliminates ambiguity: the inspector measures the pin axis relative to the datum and checks it lies within the virtual condition.

## Why Not Use an Angle Tolerance?

An angular tolerance like  $90^\circ \pm 0.1^\circ$  does not directly control linear deviation at the pin tip. A slight tilt might result in a large displacement at the free end, causing misalignment with a bushing. Perpendicularity with a tolerance zone gives a clear physical limit. For example, a perpendicularity tolerance of 0.05 mm on a 100 mm long pin means the tip can deviate by no more than 0.05 mm from perfect perpendicularity. That's a more functional requirement than an angular degree limit.

### **EXAMPLE 3: FLATNESS OF A SEALING SURFACE**

Flatness is one of the simplest yet most powerful GD&T controls.

Suppose you have a valve body where the sealing surface must be perfectly flat to prevent leaks. A flatness tolerance of 0.02 mm is specified.

**Callout:** Flatness symbol (—) with tolerance 0.02 mm.

This defines a zone defined by two parallel planes 0.02 mm apart. Every point on the surface must lie between these planes. There is no reference to any datum—flatness is a form control that stands alone. In geometric dimensioning and tolerancing examples, flatness ensures that the surface is free of waviness or warpage that would compromise the seal. Unlike a straightness tolerance on a line element, flatness covers the entire surface, providing a robust guarantee of contact.

## Inspection Methods

Inspectors typically use a surface plate and a dial indicator. The part is placed on the plate, and the indicator measures variation as it moves across the surface. The total variation must be less than 0.02 mm. This is straightforward and leaves no room for interpretation. For critical sealing surfaces, even a minor flatness violation can cause failure, making this example highly relevant in automotive and hydraulic systems.

### EXAMPLE 4: CONCENTRICITY OF A SHAFT AND BORE

Concentricity ensures that the axis of one feature coincides with the axis of another. Consider a motor shaft that must fit into a precisely machined bore. If the shaft is not concentric, it will wobble, causing vibration and premature wear.

**Callout:** Concentricity symbol (◎) with tolerance 0.05 mm relative to datum axis A.

This control creates a cylindrical tolerance zone of 0.05 mm diameter around the datum axis. The median points of the shaft surface must all lie within this zone. Concentricity is more restrictive than runout because it checks the median points, not just the surface variation. In many geometric dimensioning and tolerancing examples, engineers prefer total runout over concentricity because it is easier to measure and still ensures functional alignment. However, for high-speed rotating parts where balance is critical, concentricity provides a tighter control.

## A Better Alternative: Total Runout

For most applications, total runout (a combination of circular runout along the entire surface) is a practical substitute. It simultaneously controls concentricity and surface straightness. For instance, a total runout of 0.05 mm on a shaft relative to datum A ensures that the entire surface rotates smoothly without wobble. This is often easier to inspect with a dial indicator and a rotating chuck, making it more production-friendly.

### EXAMPLE 5: PROFILE OF A SURFACE FOR A COMPLEX CONTOUR

Modern parts often have freeform surfaces, such as turbine blades or car body panels. Traditional tolerancing cannot define

such shapes adequately. That's where profile of a surface comes in. A profile tolerance creates a 3D tolerance zone that follows the nominal surface shape.

**Callout:** Profile symbol ( $\square$ ) with tolerance 0.2 mm relative to datum A, B, and C.

This tolerance defines two surfaces offset from the nominal by  $\pm 0.1$  mm (total zone width of 0.2 mm). Every point on the actual surface must lie between these two offset surfaces. The profile control can be used with or without datums. In this geometric dimensioning and tolerancing example, the part might be an aerodynamic fairing where any deviation affects performance. Profile tolerancing allows the designer to specify the allowable variation directly on the shape, ensuring the part matches the CAD model within strict limits.

## Advantages Over Coordinate Tolerancing

Without profile tolerancing, engineers would have to specify dozens of point-to-point coordinates, each with its own tolerance, leading to an over-constrained or under-constrained part. Profile control simplifies the drawing and reduces ambiguity. It also allows for continuous variation along the surface, which is exactly what manufacturing processes like CNC machining or injection molding produce. Profile of a surface is widely used in aerospace and automotive design.

---

### EXAMPLE 6: RUNOUT CONTROL FOR ROTATING COMPONENTS

---

Runout tolerances are critical for parts like gears, pulleys, and brake rotors that rotate about an axis. Consider a gear that must mesh smoothly with its mate. A specified **circular runout** of 0.05 mm relative to datum axis A ensures that when the gear rotates, the variation at any cross-section does not exceed that value. Similarly, **total runout** would check the entire surface from one end to the other.

**Callout:** Circular runout ( $\nearrow$ ) 0.05 mm to A; or Total runout ( $\searrow$ ) 0.1 mm to A.

In practice, an inspector mounts the gear on a precision arbor, places a dial indicator against the tooth surface, and rotates the gear. The indicator reading must not fluctuate beyond the specified tolerance. Runout tolerances integrate both form and location errors. They are easier to measure than concentricity, which is why many geometric dimensioning and tolerancing examples recommend runout for rotational parts unless balance is paramount.

---

### IMPLEMENTING GD&T IN YOUR DESIGNS: BEST PRACTICES

---

Drawing from these geometric dimensioning and tolerancing examples, here are actionable tips for using GD&T effectively:

1. **Start with function.** Identify critical features that affect assembly, fit, or performance. Apply GD&T only where

needed to avoid over-tolerancing.

2. **Choose the right control.** Use positional tolerance for holes, profile for contours, perpendicularity for perpendicular features, and runout for rotating surfaces.
3. **Leverage material condition modifiers.** MMC (Maximum Material Condition) and LMC (Least Material Condition) can give bonus tolerances, reducing cost while ensuring function.
4. **Define datums logically.** Datums should correspond to functional mounting surfaces or assembly interfaces. Use a hierarchy (primary, secondary, tertiary) that reflects assembly sequence.
5. **Keep drawings readable.** Avoid cluttering the drawing with symbols. Use feature control frames consistently and add notes where necessary.
6. **Validate with inspection.** Ensure that the chosen tolerances can be measured with available equipment (CMM, gages, indicators).

---

### COMMON MISCONCEPTIONS ABOUT GD&T

---

Many engineers new to GD&T worry that it complicates drawings or increases costs. In reality, as the geometric dimensioning and

tolerancing examples above show, GD&T often simplifies communication and reduces inspection time. A common misconception is that GD&T tolerances are tighter; in fact, they are often looser because they allow more variation in non-critical directions. Another myth is that GD&T replaces all plus/minus tolerances. In practice, it supplements them, with plus/minus still used for simple dimensions like slot widths or length. Understanding these nuances helps you apply GD&T with confidence.

---

### CONCLUSION

---

Geometric Dimensioning and Tolerancing is not just a set of symbols—it is a powerful language that bridges design intent and manufacturing reality. Through the geometric dimensioning and tolerancing examples covered here—from true position and perpendicularity to profile and runout—you have seen how each control solves a specific functional problem. Whether you are designing a precision assembly, a sealing surface, or a complex contour, GD&T gives you the tools to specify exactly what you need without ambiguity. Embrace this language, and you will reduce scrap, improve part interchangeability, and accelerate production. Start applying these principles today, and watch your designs come to life with greater clarity and reliability.